

SELECTORES DE COMANDO A PALANCA																	
Modelo	∅ 22 A	7000	7100	7200	7300	7400	7500	7600	7700	8000	8100	8200	8300	8400	8500	8600	8700
	∅ 22 RP	RP300	RP304	RP310	RP350				RP380	RP400	RP404	RP410	RP450				RP480
	∅ 22 RM	RM300	RM304	RM310	RM350				RM380	RM400	RM404	RM410	RM450		RM470		RM480
Nº de Posiciones		2	2	3	2	2	3	3	3	2	2	3	2	2	3	3	3
Posicion de reposo		0-1	0-1	2-0-1	0	0	2-0	0	0	0-1	0-1	2-0-1	0	0	2-0	0	0
Posicion de retorno automatico		-	-	-	0-1	0-1	0-1	2-0-1	2-0-1	-	-	-	0-1	0-1	0-1	2-0-1	2-0-1
Movimiento de contactos																	

POSICION DE CONTACTOS SEGÚN MOVIMIENTO DE LA LEVA									
Microinterruptores Linea A, RM, RP	Normal								
		2	0	1	0	1	2	0	1
M-100									
NM-200									
NM-300									
M-400 Apertura Retardada									
NM-500 Cierre Anticipado									